



FITTING INSTRUCTIONS.

C-AJJ 3301 (RHD) ~~C-AJJ 3302 (LHD)~~

CARBURETTER INSTALLATION KIT

For 1 1/4" S. Carburetters

Comprising:-

<u>Part No.</u>	<u>Description</u>	<u>No. Off</u>
CHS 0618	Studs - Carburetter to Manifold	4
LNZ 206	Nuts - self locking for studs	4
AHH 5713	Insulators - carburetter flange	2
AEH 551	Joints - carburetter flange	4
C-AHT 1	Abutment bracket	1
ACA 5289	Trunnion	1
C-AHT 530	Double Coil Washer	1
53K 3157	Plain Washer	2
ZPS 0204	Split Pin	1
1B 2697	Trunnion, cable to stirrup	1
53K 1023	Bolt - trunnion	1
ACC 5062	Trunnion - throttle cable to lever	1
FNZ 104	Nut - trunnion	1
PWZ 203	Washer - plain	1
AEH 810	Washer - copper	1
ZPS 0310	Split Pin	1
C-AHT 2	Anchor Bracket - return spring	2
ACH 8977	Petrol Pipe - flexible connecting	1
AHB 6745 (LHD)	Petrol Pipe - flexible feed	1
C-AJJ 3302 only		

or

AHB 9059 (RHD)

C-AJJ 3301 only

NB. Trunnion ACA 5389 replaces the part shown as 11B 543 in the illustration. The end holes in the abutment bracket should be slotted a little by filing so that they match up with the hole in the carburetter out flange. The throttle cable should be fed through the abutment tube in the bracket C-AHT 1.

NB. The carburetter flare pipes illustrated are available under Part No. C-AHT 247 2 off required.

5/12/6 137

Issued by:- BRITISH LEYLAND SPECIAL TUNING DEPARTMENT,
ABINGDON-ON-THAMES, BERKSHIRE.

FITTING INSTRUCTIONS



CARBURETTER INSTALLATION KIT

C-AJJ 3301 C-AJJ 3302

